


VM1420 to VM 1220 Wiring

To convert a VM1420 to a VM1220, the inverter must be exchanged and minor wiring required.



EARTH
GROUND

208-240VAC

Remove transformer wires from **H1, H4, X1, X4**

Using 16-18 gauge wire, Jumper **H1 to X1** and **H4 to X4**